











 D-MAX	D-MAX Pickup 4 Doors 2024-10		
---	---	---	---




	Airbag		SRS control unit		High strength zone		Battery low voltage		Seat belt pretensioner
	Fuel tank content Diesel		Stored gas inflator						
		ID No.			Version No.		Version date		Page
		LSK-SK81-ICE-E001			01		10/2024		1 of 4

1. Identification / recognition




2. Immobilisation / stabilisation / lifting

A - Immobilisation / stabilisation



B - Lifting




Suitable lifting points



- 1 Turn off the ignition switch (Place the key in Off position)
- 2 Pull up the handbrake to activate the parking brake.

3. Disable direct hazards / safety regulations

Turn off - main method for disable direct hazards



- Turn off the ignition switch (Place the key in Off position)



- Disconnect the negative terminal of the battery

	ID No.	Version No.	Version date	Page
	LSK-SK81-ICE-E001	01	10/2024	2 of 4

3. Disable direct hazards / safety regulations

■ Access to 12V Battery




1




• Pull the switch once to open the hood

2




• Open the cover

3




• Disconnect 12 Volt battery

4.Access to the occupants



A: Laminated glass
B: Tempered glass

High strength body areas



Seat adjustment

1st row

Driver

Passenger

2nd row




Electric



Manual

Steering column adjustment



5. Stored energy / liquids / gases / solids

		75L
		12V
		700±30g

	ID No.	Version No.	Version date	Page
	LSK-SK81-ICE-E001	01	10/2024	3 of 4


6. In case of fire



USE LARGE AMOUNT OF WATER




7. In case of submersion















Work on the vehicle only after the vehicle has been pulled out of the water.

8. Towing / transportation / storage



9. Important additional information

10. Explanation of pictograms used

							
Flammable	Hazardous to the human health	Acute toxicity	Corrosives	Environmental hazard	Explosive	General warning sign	Vehicle on fuel of liquid group 1
							
Use water to extinguish the fire	Remove smart key	Air-conditioning component	Right hand drive				
	ID No.		Version No.		Version date		Page
	LSK-SK81-ICE-E001		01		10/2024		4 of 4